



End CapTM

Finishes the space where laminate flooring transitions from a floor to carpet.

STEP 1

Measure & trim to fit.



STEP 2

Position track 1/4" away from laminate floor. Screw to subfloor.



STEP 3

Push moulding down into track.

