



Glue Down Stair NoseTM

Finishes the end of a step.

STEP 1

Measure & trim to fit.



STEP 2

Apply glue to subfloor.



STEP 3

Push moulding down onto subfloor.

