



Stair NoseTM

Finishes the end of a step

STEP 1

Measure & trim to fit.



STEP 2

Position track 1/4" away from laminate floor. Screw to subfloor.



STEP 3

Press moulding into track.

